

WASTE-LABEL-KIT

Instructions

1. Place two (2) of the 11" x 2" decals on the front and back of the drain bowl.
2. If the drain is model TIM-315-COMP2, place the 2" x 2" decal next to the evacuation coupler.
3. If the drain is a TIM-317-A, place the 2" x 2" decal next to the air coupler.