DEF Suction Connection

Multi-Use (aka Reusable),	Multi-Use (aka Reusable),	Multi-Use (aka Reusable),
55 Gallon Drum Suction Connection	275 Gallon Tote Suction Connection	330 Gallon Tote Suction Connection
Required Components Dispense Coupler (outlet to pump) • DEF-34A (Stainless; ¾" hose barb outlet) or • DEF-34PL (Composite; ¾" hose barb outlet) or • DEF-54 (Stainless; Vapor recovery capability) Container Valve (2" Buttress (M), barbed inlet) • DEF-40A (Stainless) or • DEF-40PL (Composite) Downtube • DEF-TUBE55 (Composite, cut to length) Optional Components Tool • DEF-41 (Container valve install/remove)	Required Components Dispense Coupler (outlet to pump) • DEF-34A (Stainless; ¾" hose barb outlet) or • DEF-34PL (Composite; ¾" hose barb outlet) or • DEF-54 (Stainless; Vapor recovery capability) Container Valve (2" Buttress (M), barbed inlet) • DEF-40A (Stainless) or • DEF-40PL (Composite) Downtube • DEF-TUBE55 (Composite, cut to length) Optional Components Tool • DEF-41 (Container valve install/remove) Cap • DEF-69 (Comp., 6" Buttress (F), 2" Buttress (F))	Required Components Dispense Coupler (outlet to pump) DEF-34A (Stainless; ¾" hose barb outlet) or DEF-34PL (Composite; ¾" hose barb outlet) or DEF-54 (Stainless; Vapor recovery capability) Container Valve (2" Buttress (M), barbed inlet) DEF-40A (Stainless) or DEF-40PL (Composite) Downtube DEF-TUBE55 (Composite, cut to length) Optional Components Tool DEF-41 (Container valve install/remove) Cap DEF-69 (Comp., 6" Buttress (F), 2" Buttress (F))
Single-Use (aka Disposable),	Single-Use (aka Disposable),	Single-Use (aka Disposable),
55 Gallon Drum Suction Connection	275 Gallon Tote Suction Connection	330 Gallon Tote Suction Connection
Required Components Dispense Coupler (3/4" hose barb outlet to pump) DEF-39 (Stainless) Container Valve (2" Buttress (M), barbed inlet) DEF-42 (Composite) Downtube DEF-43 (Composite) Optional Components Tool DEF-73 (Container valve install/remove)	Required Components Dispense Coupler (3/4" hose barb outlet to pump) DEF-39 (Stainless) Container Valve (2" Buttress (M), barbed inlet) DEF-42 (Composite) Downtube DEF-44 (Composite) Optional Components Tool DEF-73 (Container valve install/remove) Cap DEF-69 (Comp., 6" Buttress (F), 2" Buttress (F))	Required Components Dispense Coupler (¾" hose barb outlet to pump) • DEF-39 (Stainless) Container Valve (2" Buttress (M), barbed inlet) • DEF-42 (Composite) Downtube • DEF-45 (Composite) Optional Components Tool • DEF-73 (Container valve install/remove) Cap • DEF-69 (Comp., 6" Buttress (F), 2" Buttress (F))

NOTE: Multi-use and single-use components are physically incompatible with one another; you cannot mix and match parts between the two systems.

NOTE: Stainless Steel and Composite components are compatible with one another within the Multi-Use system. The same is true for the Single-Use system.

NOTE: Physical positioning/connection: 1) Dispense Coupler outlet connects to pump suction hose, twist-lock into Container Valve, 2) Container Valve is intermediate between the Dispense Coupler and the Downtube, 3) Downtube outlet connects to the Container Valve inlet, downtube inlet is inserted into DEF drum/tote.