

TIM-CONV-CAM

Prepared by:

American Lubrication Equipment Corporation

Assembly

PARTS LIST

- 1 - CAMLOCK
- 1 - 3/4 OIL HOSE
- 1 - BUSHING
- 1 - 1/4 AIR HOSE
- 1 - AIR COUPLER



If needed use the bushing to attach the bushing to attach the oil hose to the tank



Attach the oil hose to tank from the 317-cam discard hose.



Make sure to attach the yellow coiled air hose to the EXIT PORT ON THE ALARM used on the waste tank.

This will prevent you from overfilling the tank while draining the 317-CAM



If you have any question or concerns, please contact us at Customerservice@americanlube.com