

---

# AMERICAN

LUBRICATION EQUIPMENT CORPORATION®

AMERICAN LUBRICATION EQUIPMENT CORPORATION  
11212A MCCORMICK ROAD, HUNT VALLEY, MD 21031  
WWW.AMERICANLUBE.COM  
CONTACT: 410-252-9300

## TIM-341

### 2-IN-1 WASTE OIL DISCHARGE AND CHANGER



*Superior Technology at an Affordable Price®*



## WARNING

Read carefully and understand all INSTRUCTIONS before operating. Failure to follow the safety rules and other basic safety precautions may result in serious personal injury.

Save these instructions in a safe place and on hand so that they can be read when required.

Keep these instructions to assist in future servicing.



## SAFETY PRECAUTIONS

### GENERAL SAFETY RULES

**WARNING: Read and understand all instructions.**

**WARNING: The warnings, cautions, and instructions discussed in this instruction manual cannot cover all possible conditions or situations that could occur. It must be understood by the operator that common sense and caution are factors which cannot be built into this product, but must be supplied by the operator.**



## WARNING


- Do not extract caustic or flammable products.
- Do not expose the reservoir to any source of heat.
- While extracting high temperature oils, keep hands and face protected.
- Only use the device for the purpose for which it has been designed.
- Do not modify any component of the equipment.
- Only use original spare parts

## PRODUCT DATA

<b>Item No.</b>	<b>TIM-341</b>
<b>Air Inlet</b>	1/4" NPT
<b>Extension Funnel</b>	Yes
<b>Capacity</b>	90L/24Gal


- Maximum air pressure for suction: 7~8bar/100~115psi
- Maximum air pressure for discharge: 1bar/14psi
- Suction speed: (oil temperature <90°C/194°F , suction tube diameterΦ6mm): 2 lpm/0.5gpm
- Suction tube length: 2000mm/78.7"
- Discharge hose length: 2000mm/78.7"
- Extension Funnel diameter: 606mm/23.8"

# ASSEMBLY




## ASSEMBLY


**Fig.1:** Assemble the handle (B) and insert the probe assembly (A), close the ball valve (H).




**Fig.2:** Assemble the vacuum gauge (D) and close the ball valve (J).



**Fig.3:** Assemble the tube, oil collecting bowl, filtrating plank and extension funnel.




**Fig.4:** Insert the assembly into the reservoir, then turn the handwheel (O) clockwise direction and tighten.




## OPERATION SUCTION

**Fig.5:** Close all the valves (K, P, J, H, I, L). Open the handwheel (E) counterclockwise direction and open the valve (L).




**Fig.7:** Connect the probe (S), then put it into the car engine, open the ball valve (J) for evacuating oil.




## COLLECTING


**Fig.8:** Close all the valves (K, P, J, H, I, L). Open the ball valve (P) and the valve (H).



**Fig.6:** Connect the air supply, open valve (K) and adjust handwheel (E) until the gauge index (F) reaches the green area.




**Fig.9:** Place the oil drainer under the car to collect the waste oil.




## DISCHARGE


**Fig. 10:** Close all the valves (K, P, J, H, I, L ).



**Fig. 12:** Connect the air supply, and open the valve (H) for discharge.



**Fig. 11:** Close the handwheel (E) clockwise direction, put the spout (M) into the waste oil tank, then open the valve (I).




## TROUBLE SHOOTING GUIDE

Problem	Cause	Solution
The index on vacuum gauge can't reach the green area.	<ol style="list-style-type: none"> <li>1. Air supply pressure is too low.</li> <li>2. Air flow is not enough.</li> </ol>	<ol style="list-style-type: none"> <li>1. Increase the air supply pressure.</li> <li>2. Increase air flow.</li> </ol>
The vacuum gauge index reaches the green area, but oil isn't evacuated.	<ol style="list-style-type: none"> <li>1. Oil temperature is too low.</li> <li>2. The suction hose, valve or fitting is jammed.</li> </ol>	<ol style="list-style-type: none"> <li>1. Increase the oil temperature</li> <li>2. Clean or replace suction hose, valve or fitting.</li> </ol>
The vacuum gauge shows leakage and can't suction the oil.	<ol style="list-style-type: none"> <li>1. O-ring of the suction fitting is broken.</li> <li>2. The bottom of the suction hose is higher than the oil level.</li> </ol>	<ol style="list-style-type: none"> <li>1. Change the O-ring.</li> <li>2. Keep the suction hose straight and ensure the hose is immersed in the oil.</li> </ol>

### **⚠ CAUTION**

- Never fill the reservoir over the maximum level indicated by the gauge that is located on the side of the reservoir.
- Don't exceed maximum pressure 1bar/14psi for discharge.
- Air pressure for vacuum is maximum 8bar/115psi.
- Open the bottom nut of the reservoir periodically and clean out any dirt.

## EXPLODED & PART LIST




Pos. No.	Description	Item No.	Q'ty	Pos. No.	Description	Item No.	Q'ty
1	Probe kit	TIM-340-PRB	1	4	Valve 1/4" NPT (F)	TIM-317-43	1
2	Tool tray	TIM-317-24	1	7	Discharge Hose 1/2" BSP	TIM-340-HOSE	1
3	Safety valve 1BAR/14PSI 1/4" BSPT	TIM-317-23	1	9	Vacuum assembly	TIM-340-VAC	1

**Note:** TIM-340-VAC Vacuum Assembly includes: gauge, manifold, valves, muffler, hose, Mercedes adapter, dust plug with chain.

**Note:** TIM-340-PRB includes probes, storage tube, BMW and Volkswagen adapters.

**Note:** Wear item O-ring kit for Mercedes/Volkswagen /BMW adapters, TIM-340-ORNG.


## OIL COLLECTING BOWL ASSEMBLY & PART LIST



Pos. No.	Description	Item No.	Q'ty	Pos. No.	Description	Item No.	Q'ty
1-1	Tube assembly 1" BSP	TIM-317-31	1	1-7	Funnel extender	TIM-317-39	1
1-2	Ball valve 1" BSP	TIM-317-32	1	1-8	Rotor (Male) 1" BSP	TIM-317-36	1
1-3	Screw M6x1	TIM-317-34	1	1-9	O-Ring, 32.9mm IDx 2.62mm DIA (sold as pair)	TIM-317-35H	1
1-4	Rotor (Female) 1" BSP	TIM-317-33	1				
1-5	Oil collecting bowl	TIM-317-37C	1				
1-6	Filtrating plank	TIM-317-38	1				



## RESERVOIR & PART LIST



Pos. No.	Description	Item No.	Q'ty	Pos. No.	Description	Item No.	Q'ty
7-1	Reservoir assembly	Not available	1	7-8	Spring washer	TIM-317-41 (each)	4
7-2	Handle	TIM-317-20	1	7-9	Acorn nut M12*1.75	TIM-317-6 (each)	4
7-3	Screw M6x1	TIM-317-17	2	7-10	Elbow M16x1	TIM-317-7 (each)	2
7-4	Valve 1/2" BSP (F) x BSP (M)	Not Available	1	7-11	Nut M16x1	TIM-317-8 (each)	2
7-5	Swivel adapter 1/2" BSP	Not Available	1	7-12	Tube with label	TIM-317-9	1
*7-6	Caster sold as pair	TIM-317-4	4	7-13	Hose clip	TIM-317-19	1
7-7	Flat washer (each)	TIM-317-5	4				

**Note:** TIM-317-4 Caster bag includes two each of the following: wheels, flat washers, lock washers, nuts.

---

---

---

---

